

Enter/Exit Configuration Mode



Recall Defaults



X

Disable Code 128



Disable Code 39



Disable Interleaved
2 of 5 (ITF)



* Disable Codabar



Disable Code 93



* Enable Code 128



neu bei Bedarf

Standard = disabled